

## Fitting the Customizable Capo

- Remove the knob and clamping jaw.
- Place the capo across the fretboard as shown in the photo below. Line the razor blade with the edge of the fretboard and press the razor blade into the tube until it bottoms against the metal rod. Pay attention that the razor blade is perpendicular with the tube.



- Carefully rotate the capo so that the razor cuts the tube perpendicular and to the depth of the metal shaft.



- Remove the excess tube
- Re-install the clamping jaw and knob

***All Done!***